

**WAC 296-307-46030 Control liquid spray over an open surface cleaning or degreasing tank.**

**You must:**

- Control the spray to the greatest extent feasible by:
  - Enclosing the spraying operation as completely as possible
  - Using mechanical ventilation to provide enough inward air velocity to prevent the spray from leaving the vapor area.

**Note:** Mechanical baffles may be used to help prevent the discharge of spray.

**Reference:** Spray painting operations are covered in Spray-finishing operations, WAC 296-62-11019.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, and 49.17.060. WSR 03-10-068, § 296-307-46030, filed 5/6/03, effective 8/1/03.]