

**WAC 296-863-40020 Meet these requirements when the operator leaves the normal operating position.** (1) You must make sure operators do the following when getting off the PIT:

- (a) Fully lower the load engaging means;
- (b) Neutralize the controls;
- (c) Set the brakes.

(2) Make sure operators do the following when leaving a PIT unattended:

- (a) Fully lower the load engaging means;
- (b) Neutralize the controls;
- (c) Shut off power;
- (d) Set the brakes;
- (e) Block the wheels, if parked on an incline.

**Note:** A PIT is unattended when the operator:  
1. Is more than twenty-five feet away; or  
2. Cannot see the PIT.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, and 49.17.060. WSR 17-18-075, § 296-863-40020, filed 9/5/17, effective 10/6/17; WSR 04-19-051, § 296-863-40020, filed 9/14/04, effective 2/1/05.]