

**WAC 296-96-24730 Protection of space beneath hoistway.** Where the space below the hoistway is used for a passageway or is occupied by people, or if unoccupied is not secured against unauthorized access, the cars and counterweights shall be equipped with safeties which shall be operated as a result of the breaking of the suspension means. Safeties may be of the inertia type without governors.

[Statutory Authority: Chapter 70.87 RCW. WSR 18-18-070, § 296-96-24730, filed 8/31/18, effective 10/1/18.]