

**WAC 296-807-15030 Use proper powder loads.** You must use only a powder load that is:

- (1) Recommended by the tool manufacturer for the particular tool;
- or
- (2) One that provides the same level of safety and performance.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050. WSR 15-23-086, § 296-807-15030, filed 11/17/15, effective 12/18/15. Statutory Authority: RCW 49.17.010, [49.17].040, [49.17].050, and [49.17].060. WSR 03-09-009, § 296-807-15030, filed 4/4/03, effective 8/1/03.]