

WAC 246-244-200 Subsurface tracer studies. (1) Protective gloves and other appropriate protective clothing and equipment shall be used by all personnel handling radioactive tracer material. Adequate precautions shall be taken to avoid ingestion or inhalation of radioactive material, and to avoid contamination of field site stations and temporary job sites.

(2) No licensee shall cause the injection or administration of radioactive material into fresh water aquifers without prior written authorization from the department and any other appropriate state agency.

[Statutory Authority: RCW 43.70.040. WSR 91-02-049 (Order 121), recodified as § 246-244-200, filed 12/27/90, effective 1/31/91. Statutory Authority: RCW 70.98.080. WSR 87-01-031 (Order 2450), § 402-38-380, filed 12/11/86.]