

**WAC 296-806-48044 Protect employees from drag saw hazards.** You must protect employees passing near a drag saw by either:

(1) Providing a four-foot clearance when the saw is at the extreme end of the stroke; or

(2) Enclosing the saw and its driving mechanism, if you cannot provide a four-foot clearance.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, 49.17.060. WSR 15-24-102, § 296-806-48044, filed 12/1/15, effective 1/5/16; WSR 04-14-028, § 296-806-48044, filed 6/29/04, effective 1/1/05.]