

**WAC 296-806-44002 Provide guards and automatic shutoffs on glue spreaders.** (1) You must enclose the in-running side of glue spreaders, leaving enough space to insert stock.

(2) You must provide an emergency stop control, such as a panic bar or similar device, that can be reached from the infeed and outfeed sides of the spreader to shut off the power in an emergency.

**Note:** You may need two controls to reach the emergency stop control from both the infeed and outfeed sides.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, 49.17.060. WSR 15-24-102, § 296-806-44002, filed 12/1/15, effective 1/5/16; WSR 04-14-028, § 296-806-44002, filed 6/29/04, effective 1/1/05.]