


**WAC 296-56-99003 Form—Appendix B—Standard signals for longshore crane signals.**

APPENDIX B


STANDARD SIGNALS FOR LONGSHORE CRANE SIGNALS



STOP



SWING LOAD IN  
DIRECTION  
FINGER POINTS



FOR MOBILE CRANES  
LOWER THE LOAD  
AND  
RAISE THE BOOM



FOR MOBILE CRANES  
HOIST THE LOAD  
AND  
LOWER THE BOOM



FOR MOBILE CRANES  
LOCK THE CRAWLER  
BELT ON SIDE  
INDICATED BY RAISED  
FIST TRAVEL OTHER  
CRAWLER BELT IN  
DIRECTION INDICATED  
BY REVOLVING FIST



FOR MOBILE CRANES  
TRAVEL BOTH CRAWLER  
BELTS IN DIRECTION  
INDICATED BY  
REVOLVING FISTS

[Statutory Authority: RCW 49.17.040 and 49.17.050. WSR 86-03-064 (Order 86-02), § 296-56-99003, filed 1/17/86; Order 74-14, Appendix D (codified as WAC 296-56-99003), filed 4/22/74; Rules (part), filed 9/24/65; Rules (part), filed 3/23/60.]