

WAC 296-869-20050 Moving the aerial lift. You must make sure the boom is properly cradled and the outriggers are in the stowed position before moving the aerial lift.

EXEMPTION: The aerial lift may be moved with the boom elevated and personnel on the platform only if the equipment was specifically designed for this type of operation.

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050. WSR 15-23-086, § 296-869-20050, filed 11/17/15, effective 12/18/15. Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, 49.17.060. WSR 06-19-073, § 296-869-20050, filed 9/19/06, effective 1/1/07.]