

WAC 246-227-080 Personnel monitoring control. (1) No registrant shall permit any individual to act as a radiographer or as a radiographer's assistant unless, at all times during radiographic operations, each such individual shall wear a film or TLD badge and a direct reading pocket dosimeter. Pocket dosimeters shall be capable of measuring exposures from zero to at least two hundred milliroentgens. A film or TLD badge shall be assigned to and worn by only one individual.

(2) Pocket dosimeters shall be read and doses recorded daily. Pocket dosimeters shall be charged at the beginning of each working day. Pocket dosimeters shall be checked at least annually for correct response to radiation. Acceptable dosimeters shall read within \pm thirty percent of the true radiation exposure. A film or TLD badge shall be immediately processed if a pocket dosimeter is discharged beyond its range during normal use. The film or TLD badge reports received from the film or TLD badge processor and records of pocket dosimeter readings shall be maintained until the department authorizes their disposal.

(3) The requirements for use of pocket dosimeter or pocket chamber shall not apply in industrial radiography utilizing radiation machines in enclosed interlocked cabinets or rooms which are not occupied during radiographic operations, which are equipped with interlocks such that the radiation machine will not operate unless all openings are securely closed and which are so shielded that every location on the exterior meets conditions for an unrestricted area, as specified in WAC 246-221-060.

(4) The requirement for film badges or TLDs do not apply to those users of cabinet X-ray systems which do not allow human access and which meet the requirements of WAC 246-227-130.

[Statutory Authority: RCW 70.98.050. WSR 94-01-073, § 246-227-080, filed 12/9/93, effective 1/9/94.]