

WAC 296-307-62010 Follow these fit-testing procedures for tight-fitting respirators.

IMPORTANT:

1. This section contains procedural requirements that apply during actual fit testing.

2. See WAC 296-307-606 of this part for fit-testing requirements that apply to the employer's overall program.

Exemption: This section does **NOT** apply to employees who:
1. Voluntarily use respirators;
OR
2. Are required to use mouthpiece respirators.

The employer must conduct fit testing according to all of the following:

(1) Follow the procedure in Table 11 to choose a respirator for fit testing:

(a) Prior to conducting fit tests;

AND

(b) Any time an employee must select a different respirator such as when a previously selected respirator fails a test.

(2) Select and follow at least one of the following fit test procedures:

(a) Qualitative fit-test procedures:

(i) Isoamyl acetate vapor (IAA, banana oil) in Table 12;

(ii) Saccharine aerosol in Table 13;

(iii) Bitrex™ aerosol in Table 14;

(iv) Irritant smoke in Table 15.

(b) Quantitative fit-test procedures:

(i) Ambient aerosol condensation nuclei counter such as the Portacount™, in Table 16;

(ii) Controlled negative pressure (CNP) such as the FitTester 3000™, in Table 17;

(iii) Generated aerosol in Table 18.

(3) Make sure employees perform the appropriate fit-test exercises listed in Table 19.

(4) Clean and maintain equipment according to the manufacturer's instructions.

(5) Make sure during fit testing employees wear any safety equipment that could:

(a) Interfere with respirator fit;

AND

(b) Be worn in the workplace. For example, chemical splash goggles.

(6) Check, prior to fit testing, for conditions that may interfere with the respirator seal or valve functions. If the employer finds such conditions, do **NOT** conduct fit testing for that individual.

Note: Examples of conditions that may interfere with the respirator seal or valve functions include:

1. Moustache, stubble, sideburns, bangs, hairline, and other types of facial hair in areas where the respirator facepiece seals or that interfere with valve function;
2. Temple bars of corrective eyewear or headgear that extend through the face seal area.

Table 11

Procedure for Choosing a Respirator for Fit Testing
<p>1. Inform the employee:</p> <ul style="list-style-type: none">• To choose the most comfortable respirator that provides an adequate fit• That each respirator sample represents a different size and, if more than one model is supplied, a different shape

Procedure for Choosing a Respirator for Fit Testing

- That if fitted and used properly, the respirator chosen will provide adequate protection

2. Provide a mirror and show the employee how to:

- Put on the respirator
- Position the respirator on the face
- Set strap tension.

Note:

This instruction does NOT take the place of the employee's formal training since it is only a review.

3. Review with the employee how to check for a comfortable fit around the nose, cheeks and other areas on the face.

- Tell the employee the respirator should be comfortable while talking or wearing eye protection.

4. Have the employee hold each facepiece against the face, taking enough time to compare the fit of each. The employee can then either:

- Reject any facepiece that clearly does not feel comfortable or fit adequately

OR

- Choose which facepiece is most acceptable and which is less acceptable, if any.

Note:

- Supply as many respirator models and sizes as needed to make sure the employee finds a respirator that's acceptable and fits correctly
- To save time later, during this step note the more acceptable facepieces in case the one chosen fails the fit test or proves unacceptable later.

5. Have the employee wear the most acceptable respirator for **AT LEAST 5 minutes** to evaluate comfort and fit. Do **ALL** of the following during this time:

- Ask the employee to observe and comment about the comfort and fit:
 - Around the nose, cheeks, and other areas on the face
 - When talking or wearing eye protection
- Have the employee put on the respirator and adjust the straps until they show proficiency
- Evaluate the respirator's general fit by checking:
 - Proper chin placement
 - Properly tightened straps (do NOT over tighten)
 - Acceptable fit across the nose bridge
 - Respirator size; it must span the distance from nose to chin
 - To see if the respirator stays in position
- Have the employee complete a successful seal check as specified in WAC 296-307-62020 of this chapter
 - Prior to the seal check they must settle the respirator on their face by taking a few slow deep breaths **WHILE SLOWLY:**
 - Moving their head from side-to-side

Procedure for Choosing a Respirator for Fit Testing

AND

- Up and down.

6. **If the employee finds the respirator unacceptable**, allow the employee to select another one and return to Step 5. Otherwise, proceed to Step 7.

7. **Before starting the fit test**, you must:

- Describe the fit test including screening procedures, employee responsibilities, and test exercises

AND

- Make sure the employee wears the respirator **AT LEAST** five minutes.

Table 12

Isoamyl Acetate (Banana Oil) Vapor Test Procedure

Important:

- This is a qualitative fit-test (QLFT) procedure
- The success of this test depends on preserving the employee's odor sensitivity to isoamyl acetate (IAA) vapor
 - Vapor accumulations in ambient air can decrease odor sensitivity. To prevent this:
 - Prepare **ALL** solutions in a location separate from screening and test areas
 - Conduct screening and tests in separate well-ventilated rooms. For example, use an exhaust fan or laboratory hood to prevent IAA vapor from accumulating in the room air
 - Always use odor-free water, for example, distilled or spring water that's 25°C (77°F).
- Isoamyl acetate is also known as isopentyl acetate.

Screening Preparations

Important:

- Odor threshold screening determines if the employee can detect weak concentrations of IAA vapor.
1. Choose an appropriate location to conduct screening.
 - Conduct screening and tests in separate well-ventilated rooms.
 2. Prepare a stock solution **AT LEAST** weekly as follows:
 - Add one milliliter (ml) of pure IAA to 800 ml of odor-free water in a one-liter glass jar with a metal lid using a measuring dropper or pipette
 - Seal the jar with the lid and shake it for 30 seconds
 - Clean the dropper or pipette.
 3. Prepare the odor test solution daily as follows:
 - Add 0.4 ml from the stock solution to 500 ml of water in a one liter glass jar with a metal lid using a clean pipette or dropper
 - Seal the jar with the lid and shake it for 30 seconds
 - Let this solution stand for 2-3 minutes so the IAA concentration above the liquid reaches equilibrium
 - Label this jar so you know the contents but the employee cannot know its contents, for example, "1."

Isoamyl Acetate (Banana Oil) Vapor Test Procedure

Note:

To maintain the integrity of the test, use labels that peel off easily AND periodically switch the labels.

4. Prepare a "test blank" solution as follows:

- Add 500 ml of odor-free water to a one liter glass jar with a metal lid
- Seal the jar
- Label the jar so you know the contents but the employee cannot know its contents.

5. Type or neatly print the following instructions on a card and place it on the table in front of the two test jars:

"The purpose of this test is to find out if you can smell banana oil at a low concentration. While both jars contain water, one ALSO contains a small amount of banana oil.

Make sure the lid is secure then pick up a jar and shake it for two seconds. Open the jar and sniff at the opening. Repeat this for the second jar.

Tell the individual conducting the fit test which jar contains banana oil."

Test Preparations

6. Choose an appropriate location to conduct fit testing.

- Conduct screening and tests in separate well-ventilated rooms.

7. Assemble the fit test enclosure in the room.

- Invert a clear 55-gallon drum liner over a circular 2-foot diameter frame made of plywood or other lightweight rigid material OR construct a similar enclosure using plastic sheeting
- Hang the frame with the plastic covering so the top of the enclosure is about six inches above the employee's head
- Attach a small hook inside top center of the enclosure
- Tape a copy of the test exercises (see Table 28) to the inside of the test enclosure where the employee can read it.

8. Have organic vapor cartridges or equivalent on hand for each employee's chosen respirator.

9. Have ready a 6 x 5-inch piece of paper towel or other porous absorbent single-ply material AND 0.75 ml of pure IAA. Do NOT apply IAA yet.

Note:

As an alternative to using the paper towel, you may use an IAA test swab OR ampoule if it has been demonstrated to generate an equivalent test concentration.

Screening

10. Have the employee, while NOT wearing a respirator, follow the instructions on the card provided.

- If the employee correctly identifies the jar containing IAA, proceed to conduct testing (Step 11)
- If the employee is NOT able to correctly identify the jar containing IAA, you must STOP and use a different fit test protocol.

Test

Isoamyl Acetate (Banana Oil) Vapor Test Procedure

11. **BEFORE** entering the fit test room, have the employee attach cartridges, put on, properly adjust, and seal check the respirator. Have the employee enter the test enclosure.
12. Wet the paper towel with 0.75 ml of **pure** IAA **AND** fold it in half.
13. Pass the paper towel to the employee inside the enclosure **AND** instruct the employee to hang it on the hook at the top of the enclosure.
14. Wait two minutes for the IAA vapor to fill the enclosure.
 - While waiting, explain the fit test, including the purpose of the test exercises, the importance of cooperation, and that you must be informed if a banana-like odor is detected during the test
 - You may also demonstrate the test exercises.
15. Have the employee perform the appropriate fit-test exercises in Table 19.
 - If the employee does **NOT** detect IAA while performing test exercises, the fit test has been **PASSED**. Proceed as follows:
 - **BEFORE** leaving the enclosure, have the employee break the respirator seal and inhale. If they **detect** IAA, the test is valid
 - When exiting the employee must remove the paper towel and give it to the individual conducting the fit test. This prevents IAA vapor from building up in the enclosure during subsequent tests
 - The individual conducting the fit test must keep used paper towels in a self-sealing plastic bag to prevent area contamination
 - If the employee detects IAA during any test exercise, the fit test has **FAILED**. **STOP** and have the employee do the following:
 - Quickly return to the selection room to remove the respirator. This avoids decreasing the employee's odor sensitivity
 - Select another respirator
 - Repeat screening and testing
 - At this stage, if the employee fails the screening part of this procedure, the employee can repeat it **AFTER** waiting at least five minutes for odor sensitivity to return.

Table 13

Saccharin Aerosol Test Procedure

Screening Preparations

Important:

- This is a qualitative fit-test (QLFT) procedure
- Taste threshold screening determines whether the employee being tested can detect the taste of saccharin

Saccharin Aerosol Test Procedure

– The employee must **NOT** eat, smoke, chew gum or drink anything but plain water for at least fifteen minutes **BEFORE** the fit test. Sweet foods or drink consumed before the test may make the employee unable to detect saccharin during screening

– Nebulizers must be thoroughly rinsed in water and shaken dry:

- Each morning and afternoon

OR

- At least every four hours.

- You may use commercially prepared solutions if they meet the requirements in this procedure.

1. Obtain a test enclosure (hood) that meets the following specifications:

- Twelve inches in diameter by fourteen inches tall
- A clear front portion
- Enough space inside to allow free movement of the head when a respirator is worn
- A 3/4 inch (or 1.9 centimeter) hole to accommodate the nebulizer nozzle. The hole must line up in front of the wearer's nose and mouth.

Note:

- An enclosure similar to the 3M hood assembly, parts #FT 14 and #FT 15 combined, meets these specifications
- This enclosure can also be used for testing.

2. Obtain and assemble two clean DeVilbiss Model 40 Inhalation Medication Nebulizers OR equivalent.

3. Prepare the screening solution as follows:

- Dissolve 83.0 milligrams of sodium saccharin USP in 100 ml of warm distilled water

OR

- **IF** you have already prepared the fit-test solution, you can make the screening solution by adding 1 ml of this solution to 100 ml of distilled water.

4. Add about 1 ml of the screening solution to one of the nebulizers.

- Mark this nebulizer to distinguish it from the one to be used for fit testing.

Test Preparations

5. Prepare the fit-test solution as follows:

- Add 83.0 grams of sodium saccharin to 100 ml of warm water.

6. Add about 1 ml of the test solution to the second nebulizer.

- Mark this nebulizer to distinguish it from the one used for screening

7. Have particulate filters ready for the employee's chosen respirator or have filtering-facepiece respirators ready.

Screening

8. Have the employee, while NOT wearing a respirator, put on the test enclosure.

9. Instruct the employee to:

- Breath through a slightly open mouth with tongue extended during screening **AND** testing

Saccharin Aerosol Test Procedure

- Immediately report when a sweet taste is detected.
10. Insert the nebulizer into the front hole of the test enclosure **AND** administer saccharin as follows:
- Direct the nozzle away from the employee's nose and mouth
 - Complete 10 squeezes in rapid succession
 - Each time firmly squeeze the bulb so it collapses completely, then release and allow it to fully expand.
11. Ask the employee if a sweet taste is detected.
- If **YES**, screening is completed. Proceed to conduct testing, Step 14, **AFTER** you:
 - Ask the employee to remember the taste for reference during the fit test
 - Note the employee's taste threshold as "10" regardless of the number of squeezes actually completed
 - If **NO**, screening must continue. Proceed to Step 12.
12. Repeat with 10 more squeezes. Then follow Step 11 again; **EXCEPT** this time note the employee's taste threshold as "20" **IF** a sweet taste is reported.
- If a sweet taste is still **NOT** detected, repeat with 10 more squeezes and follow Step 11 one last time; **EXCEPT** this time note "30" for the taste threshold **IF** a sweet taste is reported.
13. If **NO** sweet taste is reported after 30 squeezes, you must **STOP** and choose a different fit-test protocol for the employee.

Test

Important!

- Periodically check nebulizers to make sure they do not clog during use. A test is **NOT** valid if the nebulizer is clogged at the end of the test.
14. Have the employee attach particulate filters, put on, properly adjust, and seal check the respirator. Have the employee put on the test enclosure (hood).
15. Instruct the employee to immediately report if a sweet taste is detected.
16. Insert the nebulizer into the front hole of the test enclosure **AND** administer the same number of squeezes, either 10, 20, or 30, as noted during screening.
17. Have the employee perform the appropriate fit-test exercises as described in Table 19. During this step:
- Replenish the aerosol in the hood **EVERY** 30 seconds using 1/2 the number of squeezes used in Step 16, either 5, 10, or 15
 - The employee must report if a sweet taste is detected:
 - If **NO** saccharin is tasted, the test has been **PASSED**
 - If saccharin is tasted the test has **FAILED**, have the employee select another respirator **AND**
 - Repeat screening and testing.

Table 14

Bitrex™ Aerosol Test Procedure
<p>Important!</p> <ul style="list-style-type: none">• This is a qualitative fit-test (QLFT) procedure• Bitrex™ (denatonium benzoate) is routinely used as a taste aversion agent in household liquids that children shouldn't drink and is endorsed by the American Medical Association, the National Safety Council, and the American Association of Poison Control Centers• The employee must NOT eat, smoke, chew gum or drink anything but plain water for at least fifteen minutes BEFORE the fit test.
Screening Preparations
<p>Important!</p> <ul style="list-style-type: none">• Taste threshold screening determines whether the employee being tested can detect the taste of Bitrex™• Nebulizers must be thoroughly rinsed in water and shaken dry:<ul style="list-style-type: none">– Each morning and afternoonOR– At least every four hours.• You may use commercially prepared solutions if they meet the requirements in this procedure. <p>1. Obtain a test enclosure that meets the following specifications:</p> <ul style="list-style-type: none">• Twelve inches in diameter by fourteen inches tall• A clear front portion• Enough space inside the front to allow free movement of the head when a respirator is worn• 3/4 inch (or 1.9 centimeter) hole to accommodate the nebulizer nozzle. The hole must line up in front of the wearer's nose and mouth. <p>Note:</p> <ul style="list-style-type: none">• An enclosure similar to the 3M hood assembly, parts #FT 14 and #FT 15 combined, meets these specifications• This enclosure can also be used for testing. <p>2. Obtain and assemble two clean DeVilbiss Model 40 Inhalation Medication Nebulizers OR equivalent:</p> <p>3. Prepare the screening solution as follows:</p> <ul style="list-style-type: none">• Make up a 5% salt solution by dissolving 5.0 grams of salt (sodium chloride) into 100 ml of distilled water• Dissolve 13.5 milligrams of Bitrex™ in the salt solution. <p>4. Add about 1 ml of the screening solution to one of the nebulizers.</p> <ul style="list-style-type: none">• Mark this nebulizer to distinguish it from the one to be used for fit testing.
Test Preparations
<p>5. Prepare the fit test solution.</p> <ul style="list-style-type: none">• Dissolve 10.0 grams of salt (sodium chloride) into 200 ml of distilled water

Bitrex™ Aerosol Test Procedure

- Add 337.5 milligrams of Bitrex™ to the warmed salt solution.
6. Add about 1 ml of the test solution to the second nebulizer.
- Mark this nebulizer to distinguish it from the one used for screening.
7. Have particulate filters ready for the employee's chosen respirator or have filtering-facepiece respirators ready.

Screening

Important:

The employee must **NOT** eat, smoke, chew gum or drink anything but plain water for at least fifteen minutes **BEFORE** the screening and test

8. Have the employee, while **NOT** wearing a respirator, put on the test enclosure.
9. Instruct the employee to:
- Breathe through a slightly opened mouth with tongue extended during screening **AND** testing
 - Immediately report when a bitter taste is detected.
10. Insert the nebulizer into the front hole of the test enclosure **AND** administer Bitrex™ as follows:
- Direct the nozzle away from the employee's nose and mouth
 - Complete 10 squeezes in rapid succession
 - Each time firmly squeeze the bulb so it collapses completely, then release and allow it to fully expand.
11. Ask the employee whether a bitter taste is detected.
- If **YES**, screening is completed. Proceed to conduct testing, Step 14, **AFTER** you:
 - Ask the employee to remember the taste for reference during the fit test
 - Note the employee's taste threshold as "10," regardless of the number of squeezes actually completed
 - If **NO**, screening must continue. Proceed to Step 12.
12. Repeat with 10 more squeezes. Then follow Step 11 again; **EXCEPT** this time note the employee's taste threshold as "20" **IF** a bitter taste is reported.
- If a bitter taste is still **NOT** detected repeat with 10 more squeezes and follow Step 11 one last time; **EXCEPT** this time note "30" for the taste threshold **IF** a bitter taste is reported.
13. If **NO** bitter taste is reported after 30 squeezes, you must **STOP** and choose a different fit-test protocol for the employee.

Test

14. Have the employee attach particulate filters, put on, properly adjust, and seal check the respirator. Have the employee put on the test enclosure.
15. Instruct the employee to:
- Breathe through a slightly opened mouth with tongue extended during screening **AND** testing

Bitrex™ Aerosol Test Procedure
<ul style="list-style-type: none"> • Immediately report when a bitter taste is detected. <p>16. Insert the nebulizer into the front hole of the test enclosure AND administer the same number of squeezes, either 10, 20, or 30, as noted during screening.</p> <p>17. Have the employee perform the appropriate fit-test exercises as described in Table 19. During this step:</p> <ul style="list-style-type: none"> • Replenish the aerosol in the hood EVERY 30 seconds using 1/2 the number of squeezes used in Step 16, either 5, 10, or 15 • The employee must report if a bitter taste is detected: <ul style="list-style-type: none"> – If NO Bitrex™ is tasted, the test has been PASSED – If Bitrex™ is tasted the test has FAILED. Have the employee: <ul style="list-style-type: none"> ■ Select another respirator <p style="text-align: center;">AND</p> <ul style="list-style-type: none"> ■ Repeat all screening and testing steps.

Table 15

Irritant Smoke (Stannic Chloride) Test Procedure
<p>Important:</p> <ul style="list-style-type: none"> • DO NOT USE A TEST ENCLOSURE OR HOOD FOR THIS FIT TEST! • This is a qualitative fit-test (QLFT) procedure • During this test an employee is exposed to irritating smoke containing hydrochloric acid produced by a stannic chloride ventilation smoke tube to detect leakage. The smoke will irritate eyes, lungs, and nasal passages • Employee sensitivity varies, and certain employees may respond more intensely than others exposed to irritant smoke. The individual conducting the fit test must take precautions to minimize the employees' exposure to irritant smoke • Conduct fit testing in an area with adequate ventilation to prevent exposure of the individual conducting the fit test and build-up of irritant smoke in the ambient air.
Screening AND Test Preparations
<p>Important:</p> <p>Sensitivity screening is necessary to determine whether the employee can detect a weak concentration of irritant smoke AND whether any gross facepiece leakage is detected.</p> <ol style="list-style-type: none"> 1. Obtain only stannic chloride (ventilation) smoke tubes, AND an aspirator squeeze bulb OR use a low-flow air pump set to deliver 200 milliliters of air flow per minute. 2. Equip the employee's chosen respirator with P100 series filters if a negative pressure air-purifying respirator will be tested. If a powered air-purifying respirator (PAPR) will be tested equip the respirator with high-efficiency particulate air (HEPA) filters.
Screening
<p>Important!</p>

Irritant Smoke (Stannic Chloride) Test Procedure

When performing sensitivity screening checks use only the **MINIMUM** amount of smoke necessary to elicit a response from the employee.

3. Advise the employee that the smoke can be irritating to eyes, lungs, and nasal passages **AND** instruct the employee to keep eyes closed while exposed.
4. Break both ends of the ventilation smoke tube **AND** fit a short piece of plastic tubing, for example, two-to-six inches of tygon tubing, over one end to prevent exposure to the sharp end of the tube. Connect the other end to an aspirator bulb or a low-flow air pump set to deliver a flow of 200 ml per minute.
5. While the employee is **NOT** wearing a respirator, have the employee smell a weak concentration of irritant smoke to become familiar with its irritating properties.
 - Carefully direct a small amount of irritant smoke toward the employee.

Test

- Test 6. Have the employee attach respirator filters, put on, adjust, and seal check the respirator without assistance. The employee must be proficient at these tasks.
7. Remind the employee to keep eyes closed during testing.
8. Direct a stream of irritant smoke toward the respirator's face seal area as follows:
 - Begin at least 12 inches from the facepiece **AND** move the smoke around the whole perimeter of the mask
 - Gradually make two more passes around the perimeter of the facepiece, moving to within 6 inches of the respirator
 - **STOP** at any time the employee detects smoke in the facepiece. If this occurs a different respirator will need to be chosen and tested, beginning with sensitivity screening.
9. Have the employee perform appropriate fit-test exercises in Table 19 **IF** the employee has **NOT** had an involuntary response such as evidence of coughing, flinching, or other response, **OR** detected smoke in the facepiece.
 - Continue to direct smoke from a distance of 6 inches around the facepiece perimeter
 - If smoke is detected at any time the test has **FAILED**. A different respirator must be chosen and tested, starting with sensitivity screening
 - If **NO** smoke is detected proceed to Step 10.
10. Have the employee remove the respirator **AND** perform another sensitivity screening check as follows:
 - Continue to use the smoke tube used for fit testing
 - Carefully direct a **SMALL** amount of irritant smoke toward the employee
 - The test has been **PASSED IF** the employee responds to the smoke
 - The fit test is **VOIDED IF** the employee does **NOT** respond to the smoke.

Table 16

**Ambient Aerosol Condensation Nuclei Counter
(Portacount™) Test Procedure**

Important:

- This is a quantitative (QNFT) fit-test procedure
- This method uses a particle counting instrument that measures and compares the particle concentration both inside and outside the respirator facepiece while the employee performs a series of test exercises
- Particles in the ambient air are used as the test aerosol.

Test Preparations

1. Obtain a test instrument such as a Portacount™.
2. Have probed respirators available for each respirator model and size the employer uses, **OR** have a sampling adapter available if the employee's actual or chosen respirator will be tested.
Note:
 - A probed respirator has a special fitting installed on the facepiece designed to connect with the end of the test instrument's plastic sampling tube so that air samples can be taken inside the facepiece. Probed respirators can be obtained from the respirator manufacturer, or distributor, **AND** can only be used for fit-testing purposes
 - Contact TSI Inc., **OR** the respirator's manufacturer to obtain probed respirators or facepiece sampling adapters.
3. Follow the test instrument manufacturer's instructions for test preparation, including particle, zero, and system checks. Make sure the instrument's pass **OR** fail criterion is programmed to the following **MINIMUM** performance levels:
 - For half-facepiece respirators, an overall minimum fit factor of 100 as a passing level
 - For full-facepiece respirators, an overall minimum fit factor of 500 as a passing level
4. Have high-efficiency particulate air (HEPA) filters, **OR** other respirator filters available that are capable of preventing significant penetration by particles generated by the test instrument such as, P100 or N95 series filters.
 - If you'll use a sampling adapter instead of probed respirators be sure to have the correct type for the respirators chosen.

Test

5. Properly attach the sampling line to the facepiece probe or sampling adapter.
6. Have the employee attach respirator filters, put on, properly adjust, and wear the respirator five minutes **BEFORE** the fit test. During this time you and the employee must evaluate the respirator's general fit by checking:
 - Proper chin placement
 - Properly tightened straps (do **NOT** over tighten)
 - Acceptable fit across the nose bridge
 - Respirator size. It must span the distance from nose to chin
 - To see if the respirator stays in position.

**Ambient Aerosol Condensation Nuclei Counter
(Portacount™) Test Procedure**

Note:

Wearing the respirator for five minutes permits the employee to make certain the respirator is comfortable AND allows for purging of ambient particles trapped inside the facepiece.

7. Have the employee perform a seal check. Make sure the sampling line is crimped to avoid leakage during the seal check. If **NO** leakage is detected, proceed to Step 8. If leakage is detected:

- Determine the cause

AND

- If leakage is due to a poorly fitting facepiece, have the employee:

- Choose another respirator size or model

AND

- Start again at Step 6.

8. Start the fit test cycle.

- Follow the manufacturer's instructions for operating the test instrument
- Have the employee perform the appropriate fit-test exercises in Table 19

- The test instrument will automatically stop and calculate the overall fit factor. Use this result to determine whether or not the test is passed

- The test has been **PASSED** if the overall fit factor is at least 100 for a half facepiece, **OR** 500 for a full facepiece

- The test has **FAILED** if the overall fit factor is below 100 for a half facepiece or 500 for a full facepiece.

Note:

If the test has failed, have the employee select another respirator model or size following Table 11 **AND** repeat this procedure.

Table 17

Controlled Negative Pressure (CNP) Test Procedure

Important!

- This is a quantitative fit-test (QNFT) procedure
- This method determines respirator fit by measuring how much the facepiece leaks when it is subject to a slight negative pressure **AFTER** various premeasurement activities
- Measurements occur while employees remain still **AND** hold their breath for 10 seconds
- No test aerosols are used. Respirator cartridges aren't needed for this test.

Test Preparations

1. Make sure the individual conducting the fit test is thoroughly trained to perform this test.
2. Obtain a CNP test instrument such as a FitTester 3000™. Make sure:
 - Defaults are set at:
 - -15mm (-0.58 inches) of water test pressure

Controlled Negative Pressure (CNP) Test Procedure

AND

– A modeled inspiratory flow rate of 53.8 liters per minute

- It has an effective audio warning device that signals when employees fail to hold their breath.

Note:

- You are not required to obtain test recording and printing equipment such as computers OR printers. Hand recording results is acceptable
- To see default settings, check the instrument's "REDON protocol."

3. Obtain facepiece adapters appropriate for each test respirator.

Note:

- Adapters are either a one-piece (for SCBA facepieces), OR two-piece (for dual cartridge facepieces) device providing a manifold and breathing valve system. For positive pressure respirators, you will need to obtain an additional fitting, available from the respirator manufacturer, to convert the facepiece to negative pressure
- To obtain adapters, contact the CNP instrument's distributor, Occupational Health Dynamics, OR the respirator manufacturer.

Test

Important!

After the test, you must ask the employee about the comfort of the respirator **AND** if the respirator has become unacceptable, another size or model must be chosen and tested.

4. Explain the test procedure to the employee.

5. Train the employee on how to hold a breath for at least 20 seconds.

6. Prepare the respirator for the fit test as follows:

- Remove or prop open the inhalation valves. If a breathing tube is present, disconnect it
- Replace cartridges, if present, with the manifold and breathing valve adapter
 - For positive pressure facepieces, mount the manufacturer's additional fitting followed by the manifold-breathing valve adapter
- Connect the respirator to the CNP device according to the CNP instrument manufacturer's directions.

7. Have the employee put on, adjust, and seal check the respirator.

8. Turn on the instrument **AND** have the employee stand and perform the fit-test exercises in Table 19.

9. Interpret the test results:

- The test is **PASSED IF** the overall fit factor obtained is at least 100 for a half facepiece, or at least 500 for a full facepiece
- The test has **FAILED IF** the fit factor is less than 100 for a half facepiece; 500 for a full facepiece
 - If the test has **FAILED** you must have the employee select another respirator model or size following the steps in Table 11 **AND** repeat this procedure, starting at Step 6.

Table 18

Generated Aerosol Test Procedure	
Important:	<ul style="list-style-type: none"> • This is a quantitative (QNFT) fit-test procedure • In this method, a test aerosol is used to challenge the facepiece seal while aerosol concentrations inside and outside the facepiece are measured during test exercises • Special equipment is needed to generate, disperse, detect, and measure test aerosols.
Test Preparations	
1. Test aerosol.	<ul style="list-style-type: none"> • Use a particulate, for example, corn oil, polyethylene glycol 400, di-2-ethyl hexyl sebacate, or sodium chloride.
2. Instrumentation.	<ul style="list-style-type: none"> • Do ALL the following: <ul style="list-style-type: none"> – Obtain and use aerosol generation, dilution, and measurement systems appropriate for particulates – Use an aerosol-generating instrument that will maintain test concentrations within a 10% variation – Select a sampling instrument that allows for a computer record or strip chart record to be created <ul style="list-style-type: none"> ■ The record must show the rise and fall of test agent concentration during each inhalation and exhalation at fit factors of at least 2000. Note: Integrators, or computers that integrate the amount of test agent penetration leakage into the respirator for each exercise, may be used if a record of the readings is made. – Minimize the time interval between the activity and the recording of the activity so you can clearly connect what you see to what is being recorded. For example, use a small diameter and length of sampling line.
3. Test enclosure.	<ul style="list-style-type: none"> • Do ALL the following: <ul style="list-style-type: none"> – Make sure the enclosure is equipped and constructed to effectively: <ul style="list-style-type: none"> ■ Maintain a uniform concentration of the test agent inside the enclosure. For example, the enclosure must be large enough to allow ALL employees freedom of movement during testing WITHOUT disturbing the test concentration or measurement instrument ■ Keep the test agent from contaminating the air outside the enclosure. For example, use a HEPA filter to purify exhausted air ■ Allow the individual conducting the fit test to view the employee during the test – Make sure the tubing used to collect samples from the enclosure AND respirator is the same material, diameter, AND length. This makes the effect of aerosol loss caused by deposition in each sample line equal – If sodium chloride is used, relative humidity inside the enclosure must be kept below 50%.
4. Prepare test respirators.	<ul style="list-style-type: none"> • Do ALL the following: <ul style="list-style-type: none"> – Inspect test respirators regularly for missing parts AND damage – Keep test respirators in proper working order – Make sure in-mask sampling probes are: <ul style="list-style-type: none"> ■ Designed and installed so the air sample will be drawn from the employee's breathing zone; midway between the nose and mouth AND <ul style="list-style-type: none"> ■ The probe extends inside the facepiece at least 1/4 inch – Make sure sampling ports such as probes, or adapters on respirators are constructed and installed so they do NOT: <ul style="list-style-type: none"> ■ Block air flow into the sampling line ■ Leak ■ Interfere with the respirator's fit or performance • Have high efficiency particulate air (HEPA) filters OR P100 series filter available <ul style="list-style-type: none"> – Replace filters when increased breathing resistance is detected OR when the test agent has altered the filter material's integrity.
Test	

Generated Aerosol Test Procedure

Important!

- Throughout the test, maintain the employee's exposure to any test agent below the established exposure limit. Exposures allowed must be based on exposure time and exposure limit duration

- If a single peak penetration exceeds 5% for half facepieces OR 1% for full facepieces:

- STOP the test

AND

- Have the employee select another respirator for testing.

5. Have the employee attach filters, put on, adjust, and seal check the respirator.

- Be sure to crimp the sampling line to avoid pressure leaks during the seal check

AND

- Have the employee adjust the respirator straps, without assistance, so the fit is comfortable. Do NOT over tighten.

6. **OPTIONAL Step.** To save time conduct a screening test to quickly identify poorly fitting respirators.

Note: You may use a qualitative screening test OR an ambient aerosol condensation nuclei counter instrument in the count mode.

7. Make sure test aerosol concentration is reasonably stable.

- If a canopy or shower curtain enclosure is used, determine stability of the test aerosol concentration **AFTER** the employee enters the enclosure.

8. Have the employee enter the test enclosure and connect the respirator to the sample lines.

9. Immediately after entering the enclosure measure test aerosol concentration inside the respirator.

- Make sure the peak penetration does NOT exceed 5% for half facepieces, OR 1% for full facepieces.

10. Have employee perform the appropriate fit-test exercises in Table 19.

- Do NOT adjust the respirator once exercises begin.

11. Calculate the overall fit factor as specified in Steps 12-13. The fit test is:

- PASSED IF the minimum fit factor of 100 for half facepieces OR 500 for full facepieces is obtained

OR

- IF a passing fit factor is NOT obtained, the test has FAILED and you must have the employee select and test another respirator.

Calculations

Important!

- Do NOT count the grimace exercise measurements during these calculations

- Take into account the limitations of instrument detection when determining fit factors.

12. Calculate individual fit factors for EACH exercise by applying the following:

Exercise fit factor (ffE) = $\frac{\text{Average test enclosure concentration}}{\text{Test aerosol concentration inside the respirator}}$

Test aerosol concentration inside the respirator

- To determine the average test enclosure concentration use one of the following methods:

- Arithmetic average of the concentration before and after each **test** (an average of two values per entire test)

- Arithmetic average of concentration before and after each **exercise** (an average of two values per exercise)

- True average measured continuously during the respirator sample

- Determine the test aerosol concentration inside the respirator in one of the following ways:

- Average peak penetration values. Determine aerosol penetration for each exercise by:

- Using integrators or computers that calculate the actual test agent penetration

OR

- Average the peak heights shown on the strip chart recording, graph, or by computer integration

- Maximum peak penetration. Use strip chart recordings to determine the highest peak penetration for each exercise and use this value

Generated Aerosol Test Procedure

– Area under the peaks. Use computerized integration or other appropriate calculations to integrate the area under individual peaks for each exercise.

13. Using individual exercise fit factors (ffE) calculate the **overall fit factor** by doing **ALL** of the following:

- Convert each exercise fit factor to a penetration value
- Determine the average penetration value
- Convert the average penetration value back to a fit factor

OR

- Use this equation to calculate the **overall fit factor**:

$$\text{Overall fit factor} = \frac{n}{1/\text{ffE}1 + 1/\text{ffE}2 + 1/\text{ffE}3 \dots + 1/\text{ffE}n}$$

Table 19

Fit-Test Exercises

Important:

- This list applies when you use any fit test
- Employees tested must perform **ALL** exercises marked with an "X" as described for the fit-test procedure used
 - Once exercises begin, any adjustments made void the test **AND** you must begin again
 - After test exercises are completed, you must ask the employee about the comfort of the respirator. If it has become unacceptable, have the employee choose another one for testing
- When the controlled negative pressure procedure is used, **STOP and repeat** the test if the employee adjusts the respirator OR takes a breath and fails to hold it for 10 seconds
- Controlled negative pressure tests conducted according to the method published in 29 C.F.R. 1910.134, Appendix A are an acceptable alternative to the method outlined below.

Description of Required Fit-Test Exercises	Fit-Test Procedures		
	Qualitative Procedures	Quantitative Procedures; EXCEPT the CNPP	Controlled Negative Pressure Procedure (CNPP)
<ul style="list-style-type: none"> • Normal breathing <ul style="list-style-type: none"> – Breathe normally, while standing for one minute 	X	X	
<ul style="list-style-type: none"> • Deep breathing <ul style="list-style-type: none"> – Breathe slowly and deeply while standing for one minute – Take caution to avoid hyperventilating 	X	X	
<ul style="list-style-type: none"> • Head side to side <ul style="list-style-type: none"> – Slowly turn head from side to side while standing for one minute, pausing at each extreme position to inhale – Be careful to NOT bump the respirator 	X	X	
<ul style="list-style-type: none"> • Head up and down <ul style="list-style-type: none"> – Slowly move head up and down while standing for one minute, inhaling in the up position – Be careful to NOT bump the respirator 	X	X	
<ul style="list-style-type: none"> • Talking <ul style="list-style-type: none"> – Talk slowly and loud enough to be heard clearly by the individual conducting fit testing for one minute. Choose ONE of the following: <ul style="list-style-type: none"> ■ Read from a prepared text such as the Rainbow Passage¹ ■ Count backward from 100 	X	X	

Fit-Test Exercises			
■ Recite a memorized poem or song.			
• Grimace – Smile or frown for fifteen seconds.		X	
• Bending over – Bend over to touch toes while standing. Repeat at a comfortable pace for one minute OR – Jog in place for one minute if the test enclosure, such as a hood, does not permit bending over	X	X	
• Normal breathing – Breathe normally while standing for one minute	X	X	
• Face forward – Premeasurement activity: Stand and breath normally, without talking – Measurement position: Face forward while holding breath for 10 seconds			X
• Bending over – Premeasurement activity: While standing, bend over to touch toes – Measurement position: Hold the bending position with face parallel to the floor while holding breath for 10 seconds			X
• Head shaking – Premeasurement activity: Vigorously shake head from side to side for 3 seconds while shouting or making the sound of "BRRRR" loudly – Measurement position: Face forward, while holding breath for 10 seconds			X
• Redon-1 – Premeasurement activity: Remove the respirator completely and put it back on – Measurement position: Face forward while holding breath for 10 seconds			X
• Redon-2 – Repeat the premeasurement activity and measurement position described in Redon-1			X

¹ The Rainbow Passage:
"When the sunlight strikes raindrops in the air, they act like a prism and form a rainbow. The rainbow is a division of white light into many beautiful colors. These take the shape of a long round arch, with its path high above, and its two ends apparently beyond the horizon. There is, according to legend, a boiling pot of gold at one end. People look, but no one ever finds it. When a man looks for something beyond reach, his friends say he is looking for the pot of gold at the end of the rainbow."

[Statutory Authority: RCW 49.17.010, 49.17.040, 49.17.050, and 49.17.060. WSR 20-21-091, § 296-307-62010, filed 10/20/20, effective 11/20/20; WSR 05-01-166, § 296-307-62010, filed 12/21/04, effective 4/2/05.]